User's 96036

Manual Clamp-on Probe

Thank you for purchasing our Clamp-on Probe. This manual describes the specifications and handling precautions for a Clamp-on Probe.

The following manuals, including this one, are provided as manuals for the 96036. Read them along with this manual.

IM 96036-E: User's Manual (this manual)

IM WEEE001E: Waste Electrical and Electronic Equipment

IM CROHS-96030: Document for China

Contact information of Yokogawa offices worldwide is

provided on the following sheet.

PIM 113-01Z2: Inquiries List of worldwide contacts

Store this manual in an easily accessible place for quick reference.

All Rights Reserved, Copyright © 2015, Yokogawa Meters & Instruments Corporation 2017, Yokogawa Test & Measurement Corporation Printed in Japan



IM 96036-E

Yokogawa Test & Measurement Corporation 7th Edition: Oct. 2017 (YMI)

Sales in Each Country or Region

Authorized Representative in the EEA

Yokogawa Europe B.V. is the authorized representative of Yokogawa Test & Measurement Corporation for this product in the EEA. (EEA: European Economic Area)

To contact Yokogawa Europe B.V., see the separate list of worldwide contacts, PIM 113-01Z2.

Regarding Safe Use of This Product

This product is designed to be used by a person with specialized knowledge. When operating the instrument, be sure to observe the cautionary notes given below to ensure correct and safe use of the instrument. If you use the instrument in any way other than as instructed in this manual, the instrument's protective measures may be impaired. This manual is an essential part of the product; keep it a safe place for future reference.

YOKOGAWA is by no means liable for any damage resulting from use of the instrument in contradiction to these cautionary notes.

The following safety symbols are used on the instrument and in this manual.



Indicates a hazard that may result in the loss of life or serious injury of the user unless the described instruction is abided by.



Indicates a hazard that may result in an injury to the user and/or physical damage to the product or other equipment unless the described instruction is abided by.



Danger! Handle with Care.

This mark indicates that operator must refer to an explanation in the instruction manual in order to avoid risk of injury or death of personnel or damage to the instrument.



This symbol indicates that this instrument designed to be applied around or removed from HAZARDOUS LIVE conductors provided if the RATED circuit-to-earth voltage dose not exceed the value indicated in the measurement category.

This symbol indicates AC voltage/current.

☐ This

This symbol indicates double insulation.

Strictly observe the following cautionary notes in order to avoid the risk of injury or death of personnel or damage to the instrument due to hazards such as electrical shock.



- This instrument is for measuring AC current (clamping sensor).
 Do not use this instrument for other purpose.
- Do not use the instrument if there is a problem with its physical appearance.
- To avoid a short-circuit or an accident to personnel, use this product within the RATED circuit-to-earth voltage of measurement category.
- Do not use the product when there are raindrops or droplets of condensed water on its surface, or if your hands are wet.
- Barrier is for to avoid touching the HAZARDOUS LIVE conductor.

Be careful not to across the Barrier when using the instrument.

- Safety protectors such as rubber-insulated gloves should be worn to prevent electrical shock when using the instrument.
- Do not use this product in a place where an explosive gas or vapor is present.
- Do not use the instrument if there is any damage to the casing or when the casing is removed. Do not attempt to repair/modify the product yourself, as doing so is extremely dangerous.
 Should an abnormality or failure in the product be found, contact the vendor from which you purchased the product.

! CAUTION

- The clamping JAWS are precision assembled to ensure high performance. When using the clamp, do not apply intense mechanical shock, vibration, or force to the clamping JAWS.
- If dust or any other foreign matter gets in the clamping JAWS, do not close the clamping cores tight. First remove the dust and then make sure the clamping cores on both sides close smoothly.

∴ CAUTION

This product is a Class A (for industrial environments) product. Operation of this product in a residential area may cause radio interference in which case the user will be required to correct the interference.

Cleaning

To remove dirt, disconnect the connector and gently wipe the outer surface with a clean and soft cloth.

Do not use a chemical agent such as benzene or paint thinner.

Measurement Category

. WARNING

The 96036 is designed for measurement category III. Do not use the 96036 for measurements in locations falling under Measurement Categories IV.

Measurement category	Description	Remarks
O (None, Other)	Other circuits that are not directly connected to MEAINS.	Circuits not connected to a mains power source.
CAT II	For measurement preformed on circuits directly connected to a low-voltage installation.	Appliances, portable equipment, etc.
CAT III	For measurement preformed in a building installation.	Distribution board, circuit breaker, etc.
CAT IV	For measurement preformed at the source of a low-voltage installation.	Overhead wire, cable systems, etc.

**- 1-1 00000


For Precise Measurements

Use this product under the following ambient conditions.

Temperature: 23 ±5°C

Relative humidity: 35 to 75% (no condensation)

- When performing a measurement, hold the probe so that the measured conductor cable runs at the center of the clamp.
- Ensure that the orientation of the clamp to the direction of the conductor cable (power source → load) is correct as shown right.
- Ensure that the clamping JAWS are properly closed.



Specifications

Item		Model 96036	
Measurem	ent range	0 to 2 Arms AC	
Output volt	age	0 to 50 mVrms AC (25 mV/A)	
Accuracy	Amplitude	±1.5%rdg ± 0.04 mV (20 Hz to 45 Hz)	
		±0.5%rdg ± 0.01 mV (45 Hz to 66 Hz)	
		±0.8%rdg ± 0.02 mV (66 Hz to 1 kHz)	
		±2.0%rdg ± 0.04 mV (1 kHz to 5 kHz)	
	Phase	Within ±2°(45 Hz to 3.5 kHz)	
(Tested at 23 ±5°C and 35 to 75%		6 relative humidity and with sine wave input)	
Temperature coefficient		0.05% of full scale/°C	
		over 0 to 18°C and 28 to 50°C ranges	
Maximum allowable current		60 Arms AC (45 Hz to 66 Hz)	
		20 Arms AC (66 Hz to 3.5 kHz)	
Output impedance		Approx. 70 Ω	
Effect of external		2 mA equivalent or less	
magnetic fi	elds	(400 A/m, 50/60 Hz)	
		±30 ppm max.	
		(for an electric current of 100 A flowing	
		through the adjacent electric wire)	
Effect of co	onductor position	Within ±0.5%	
		(0.2 to 2 A, 45 Hz to 1 kHz)	
The RATE	D circuit-to-earth voltage	50 Vrms AC max.	
Withstand	voltage	2.7 kV AC for one minute	
		(between core and case and between	
		core and output)	
Measurable	e conductor diameter	ϕ 40 mm max.	
Operating t	temperature and	0 to 50°C, 5 to 85% RH	
humidity ranges		(no condensation)	
Storage temperature and		-20 to 60°C, 90% RH max.	
humidity ranges		(no condensation)	
External dimensions		Approx. 70 (W) x 120 (H) x 25(D) mm	
		(excluding protrusions)	
Weight		Approx. 300 g	
Output cable length		Approx. 3 m	
		(Output terminal: Safety banana plug)	
Accessory		User's manual (1),	
		Ring markers (4 colors x 2): L4007MG	

Safety standards

EN 61010-1, EN 61010-2-032

Measurement category III

(The RATED circuit-to-earth voltage: 50 Vrms)

Indoor use, Altitude 2000 m or less, Pollution degree 2

Pollution degree

The pollution degree of the 96036 in the operating environment is 2. Pollution Degree applies to the degree of adhesion of a solid, liquid, or gas which deteriorates withstand voltage or surface resistivity. Pollution Degree 2 applies to normal indoor atmospheres.

Normally, only nonconductive pollution is emitted. However, a temporary electrical conduction may occur depending on

EMC standards

EN 61326-1 Class A

the concentration.

EN 55011 Class A Group 1

EMC Regulatory Arrangement in Australia and New Zealand EN 55011 Class A Group 1

Environmental standard:

EN 50581

Monitoring and control instruments including industrial monitoring and control instruments

External Dimensions

Current Clamp-on Probe

Unit: mm (inch)

