User's Manual

AQ2200 Series Multi-Application Test System Remote Viewer



IM 735101-62EN 4th Edition

Foreword		
	This user's man operating proce program that is please read this After reading th question arises For information the AQ2200 Mu Windows, see th	nual contains useful information about the precautions, functions, and edures of the AQ2200 Multi-Application Test System Remote Viewer downloadable from https://y-link.yokogawa.com. To ensure correct use, a manual thoroughly during operation. e manual, keep it in a convenient location for quick reference whenever a during operation. about the handling precautions, functions, and operating procedures of liti-Application Test System, and the handling and operating procedures of he manuals that accompany the particular instrument you are using.
Notes	 The contents continuing in given in this Every effort to of its content contact your 	s of this manual are subject to change without prior notice as a result of hprovements to the instrument's performance and functions. The figures manual may differ from the actual screen. has been made in the preparation of this manual to ensure the accuracy ts. However, should you have any questions or find any errors, please nearest YOKOGAWA dealer.
Trademarks	 Microsoft, W trademarks of Adobe and A For purposes respective tra- other compa- respective con- Copying or re- YOKOGAWA 	indows, Windows 7, and Windows 8 are either registered trademarks or of Microsoft Corporation in the United States and/or other countries. Acrobat are trademarks of Adobe Systems incorporated. Is of this manual, the TM and ® symbols do not accompany their ademark names or registered trademark names. Any and product names are trademarks or registered trademarks of their companies. Peproducing all or any part of the contents of this manual without A's permission is strictly prohibited.
Revisions	1st Edition: 2nd Edition 3rd Edition 4th Edition	September 2009 October 2009 December 2014 October 2017

Contents

Product Overview	1
Notes on Using the Software	3
1. Controlling the AQ2211/AQ2212 Frame Controller	4
2. Control Window Operation	6
	0

Product Overview

Functions

Controlling the AQ2200 Multi-Application Test System

Enables the AQ2200 Multi-Application Test System to be controlled from your PC via the Ethernet interface. When the software program starts, the front panel image of the connected AQ2200 Multi-Application Test System (control panel) appears on the monitor of your PC. Using a mouse, you can control the AQ2200 Multi-Application Test System from your PC through operations that are similar to those for the front panel keys of the instrument.

Control Screens



PC System Requirements

PC

A PC running Windows 7 or Windows 8.1 with a CPU capable of running the OS smoothly and at least 256 MB of memory.

Operating System

Windows 7(32-bit/64-bit) or Windows 8.1(32-bit/64-bit)

Hard Disk Space

At least 10 MB of free space for the installation.

Display

Resolution: 1024 x 768 dots or better Color: 256 colors or more (65536 colors or more recommended)

Firmware Version of the AQ2200 Multi-Application Test System Required for Operation

Version 1.01 or later

Notes on Using the Software

Exemption from Responsibility

YOKOGAWA shall not be held responsible by any party for any losses or damage, direct or indirect, caused by the use or any unpredictable defect of the product.

Precautions Concerning the Use of the Software

- Do not perform operations directly on the AQ2200 Multi-Application Test System while using this software program. Doing so can lead to erroneous operation.
- If the standby mode provided on your PC is activated, the operation of the software may not be able to continue.

When using the software, turn OFF the standby mode.

• If you run the software using a NIC interface, the line load is 800 kbytes/s maximum and 400 kbytes/s or less in normal conditions.

Consult your network administrator on using the NIC interface.

- Do not set the network or communication parameters of the AQ2200 Multi-Application Test System using this software program. The connection may be disconnected.
- Only a single AQ2200 Multi-Application Test System can be controlled by this software program. Additionally, you can connect a maximum of five PCs to the same AQ2211/ AQ2212 frame controller at the same time.
- You can run multiple instances of the software program on a single PC to control multiple AQ2200 Multi-Application Test System. However, the operation may slow down depending on the specifications of your PC or the line condition. In addition, the program may not operate properly if multiple copies of the program are running simultaneously, depending on the CPU or memory size of your PC.
- If a connection error occurs when connecting to a AQ2200 Multi-Application Test System, power cycle the AQ2200 Multi-Application Test System.

1. Controlling the AQ2211/AQ2212 Frame Controller

Setting the Ethernet Interface

1. Press **SYSTEM** on the front panel of the AQ2211/AQ2212 frame controller, and select Network Set. The Network Set screen appears.

SYST	EM		
IP Address	192.168.0.1	Close	
SubNetmask	255.255.255.0		
Gateway	192.168.0.254		
Port: 50000	DHCP:Off		
Networl	< Set		
IP Address 192 SubNetmask 255	168 0 1 255 255 0		Sot the items as necessary
L Gateway 192	168 0 254		Set the items as necessary
F Port	50000		
[DHCP	Off		
Daterrime			

For details on how to set the items, see the AQ2200 Multi-Application Test System User's Manual (IM735101-03JA).

Starting the Software

- Decompress the downloaded ZIP file (AQ2200SeriesRemoteViewer.zip) to create the following files in the target directory.
 AQ2200SeriesRemoteViewer.exe
 AQ2200SeriesRemoteViewer.INI
- 3. Double-click AQ2200SeriesRemoteViewer.exe.

The AQ2200 Series Remote Viewer dialog box appears.

4. Specify the IP address and port number of the AQ2211/AQ2212 frame controller that you are connecting to.

🔜 AQ2200 Series	s Remote Viewer	×
IP Address	192 168 0 1	
Port	50000	
	ОК	

Note .

You cannot use port number 10001 because it is reserved for a different protocol.

Controlling the AQ2211/AQ2212 Frame Controller

5. Click **OK**. The front panel image (control window) of the AQ2211/AQ2212 frame controller that you are connecting to appears.

Move the cursor to the key you wish to operate and click to carry out the same operation as when the front panel key is pressed.



Note -

For details on how to operate the AQ2200 Multi-Application Test System, see the user's manual for the AQ2200 Multi-Application Test System.

2. Control Window Operation

Using the Mouse

The following table shows the mouse icon and operation and the corresponding operation on the AQ2211/AQ2212 frame controller.

Mouse Pointer Position	Displayed Icon and Mouse Operation	Operation	
Operation key	宁		
	Click operation	Same as pressing the operation key	